

INSTALLATION INSTRUCTIONS:

1) SAME INSTRUCTIONS FOR 8, 13 & 15 PLATE KITS. 8 PLATE KIT SHOWN.

2) FOLLOW THE PROVIDED INSTRUCTIONS THAT COME WITH THE COOLER KITS TO INSTALL IN THE COOLER HOUSING.

3) APPLY RED LOCTITE TO THE END OF 90031C200SSS STUDS, FIG. A. USING 5/32 ALLEN KEY, INSTALL INTO THE OUTSIDE HOLES IN THE COOLER HOUSING, FIG. B.

4) APPLY ANTI-SIEZE TO THE ALLEY KEY SIDE OF THE STUDS.

5) SLIDE COOLER ASSEMBLY INTO THE 2 UPPER HOLES IN THE BRAVO BELLHOUSING.

6) SLIDE 90031AN-STSS WASHERS OVER STUDS. INSTALL 90031CN-FNSS NUTS. USING A 1/2 SOCKET, TORQUE TO 20 FT. LBS..